

DESPICE KB430

位置号 Pos No	供应商零件号 Manufacturer Part Number	零件中文名称 Part Name Chinese	零件英文名称 Part Name English	数量 Quantity
1	8440-463112	油箱盖组件	Oil box cap assy	1
1-1	8185-463102	油箱盖罩	Cover the cap	1
1-2	8020-463103	油箱盖	Oil box cap	1
1-3	8335-463102	阀门	Valve	1
1-4	8208-472201	密封圈	Seal ring	2
2	8SJAB40-16B	自攻螺钉 16B	Self tapping screw	18
3	8440-433804	电机罩组件	Motor cover component	1
3-1	8024-433801-01	电机罩	Motor cover	1
3-2	8326-433801	过滤海绵	Filter sponge	1
4	8414-433803	36V无刷控制器	Brushless controller	1
5	8440-433803	油箱组件	Oil box assy'	1
5-1	234-1003	透明油管	Transparent oil tube	0,06
5-2	8208-462503	油箱出油口密封圈	Oil outlet seal	1
5-3	8213-471001	油箱直接头	Oil box direct joint	1
5-4	8326-462701	海绵	Sponge	1
5-5	8348-462701	油箱接头堵头	Oil box joint core plug	1
5-6	8165-433501	油箱	Oil box	1
6	8SJAB50-20B	自攻螺钉 20B	Self tapping screw	10
7	8006-433501-01	左机壳	Left housing	1
8	8312-433501	反自锁按钮	Lock off button	1
9	8342-463002	按钮弹簧	Button in the spring	1
10	8342-432101	开关扭簧	Switch torsion spring	1
11	8044-433501	开关扳机	Switch trigger	1
12	8186-481202	压板	Clamp	2
13	8SNAB30-12B	法兰面自攻螺钉 12B	Self tapping screw	2
14	8304-433201	防护板定位块	Protective positioning boards	1
15	8342-433502	锁止弹簧	Locking spring	1
16	8202-240601	平垫片	Flat gasket	1
17	8081-433501	防护板轴	Protective shield shaft	1
18	8440-433802	电机油泵组件	Oil pump assy	1
18-1	8440-491208	油泵组件	Oil pump assy	1
18-1-1	8123-472201	涡轮齿	Turbine tooth	1
18-1-2	8121-472201	蜗轮	Worm gear	1
18-1-3	8292-472203	活塞支架	The piston stents	1
18-1-4	8342-491201	油泵拉簧	Oil pump tension spring	1
18-1-5	8336-472203	油泵主体	Main part of oil pump	1
18-2	8SNAB30-12B	法兰面自攻螺钉 12B	Self tapping screw	2
18-3	8440-433801	电机组件	Motor assy'	1
18-3-1	8BC-264008-ST	6000轴承	600Z bearing	1
18-3-2	8403-433801	风叶	The wind leaf	1
18-3-3	8402-433801	转子总成	The rotor	1
18-3-4	8BC-264008-ST	6000轴承	600Z bearing	1
18-3-5	8SJAB40-16B	自攻螺钉 16B	Self tapping screw	4
18-3-6	8024-433802	导风罩	wind scooper	1
18-3-7	8405-433801	定子总成	The stator	1
18-3-8	8292-433801	电机支架	Motor bracket	1
18-4	243-1003	透明油管	Transparent oil tube	0,1
18-5	8065-481201	出油嘴	Out of the nozzle	1
18-6	8204-462201	O型橡胶圈	Rubber ring	2
19	8SJAB40-12B	自攻螺钉 12B	Self tapping screw	1
20	8182-471902	压板	Clamp	1
21	8206-462902-02	M8螺柱	M8 stud	1
22	8SJAB30-06B	自攻螺钉 16B	Self tapping screw	2
23	8186-433501	压板	Clamp	1
24	8006-433801-02	右机壳	Right housing	1
25	8SJAB30-16B	自攻螺钉 16B	Self tapping screw	1
26	8181-433501	缓冲板	Dead block	1
27	8342-462304	张紧弹簧	Tensioning spring	1

28	8128-462201	链齿	Sprocket	1
29	8CE-07B	E型卡圈	E-check ring	1
30	8202-491802	隔热垫片	Thermal insulation gasket	1
31	8SEAB40-12B	沉头自攻螺钉 12B	Self tapping screw	2
32	8208-491801-01	出油口密封圈	Oil-out seal ring	1
33	8206-462302	推板拉紧螺钉	Tensioning screw	1
34		刀套	The knife set	1
35		链板	Guide bar 12"	1
36		链条	Chain saw 12"	1
37	8208-462304	推板密封圈	Seal ring	1
38	8440-494101	盘旋轮组件	Circle wheel component	1
38-1	8204-462301	卡圈	Retainer ring	1
38-2	8186-462301	压板	Clamp	1
38-3	8121-491102	盘旋轮	Circle wheel	1
38-4	8121-491101	推板	Push pedal	1
38-5	8331-462301	连接套	Connected set of	1
39	8021-433501	端盖	End cover	1
40	8CC-19B	轴用卡簧	Axis with the spring	1
41	8313-462301	调节旋钮	Adjusting knob	1
42	8342-462305	压紧旋钮弹簧	Knob spring	1
43	8313-462302	压紧旋钮	Knob	1
44	8185-433501	防护板	Preventer plate	1
45	8020-433501	上盖	The lid	1
46	8342-751301	复位弹簧	Reset spring	1
47	233-1008	热收缩管	Heat shrinkable tube	3
48	8SJAB40-25B	自攻螺钉 25B	Self tapping screw	4
49	8003-433501	前把手	Before hand	1

